



Thank you for selecting Casabianca Home and letting us become part of your story.

Assembly Tips:

- * Assemble this product on soft, scratch-free surface such as a carpet or cardboard to prevent scratching on the product.
- * Sometimes hardware can be found inside drawers or underneath products.
- * Do not discard any of the packaging until you have successfully assembled the product.



ENTERTAINMENT CENTER

CB-4920TV-WAL
5414-WAL



DOWNLOAD OUR APP AT
"CASABIANCA HOME
3D EXPERIENCE"



GENTLE WARNING

You will love it so much you'll never want to leave home!

Care Instructions

Casegoods (C): Dust with a soft, dry cloth. All spills should be cleaned up immediately. Use glass cleaners on glass only. DO NOT use any abrasive cleaning supplies.


We're here to help.



Need a little help with setup or hardware? Simply contact our support team at

support@casabiancafurniture.com

1(800) 652-6344

Mon-Fri 9:00am - 5:00pm EST






A x8
Spec: ϕ 3.8x16



B x5
Spec: ϕ 3.5x50



1
